
Subject: Re: meaning of 'up' and 'down' in mileageChange.dir and track.mainDir
Posted by [christian.rahmig](#) on Mon, 21 Jan 2019 12:15:38 GMT

[View Forum Message](#) <> [Reply to Message](#)

Dear all,

Am 13.04.2012 um 16:39 schrieb Susanne Wunsch:

> [...]

>> In my examples on mileage I wrote that the values 'up' and 'down' of
>> the attributes 'mileageChange.dir' and 'track.mainDir' relate to
>> numerical interpretation (raising, falling = "to count up or
>> down"). Therefore, they differ from the typical usage in British
>> English where 'up' relates on "direction to London" and 'down'
>> relates on "direction away from London".

>

> From the next major release on this enumeration values should be renamed
> to "raising" and "falling". See also Trac ticket #145 [1]

>

>> therefore differ from the usage of the attribute mileageChange.dir,
>> where 'dir' of course refers to the `_absolute_` mileage direction.

>

> From the next major release on this attribute should be renamed to
> "absDir". See also Trac ticket #144 [2]

In railML 3.1, mileage changes are modelled using `<anchor>` points of
`<linearPositioningSystem>`. I added a detailed example in the description
of Trac ticket #144 [2]. Considering this proposal, an attribute `@dir` or
`@absDir` is not needed.

> [1] <http://trac.assembla.com/railML/ticket/145>

> [2] <http://trac.assembla.com/railML/ticket/144>

Best regards

Christian

--

Christian Rahmig - Infrastructure scheme coordinator

railML.org (Registry of Associations: VR 5750)

Phone Coordinator: +49 173 2714509; railML.org: +49 351 47582911

Altplauen 19h; 01187 Dresden; Germany www.railml.org
