Subject: Re: V1.00 RC1: open discussion points, part 2 Posted by Gregor. Theeg on Tue, 26 Oct 2004 11:09:17 GMT View Forum Message <> Reply to Message

Hello,

Thanks to Matthias Hengartner for his ideas. My answer to his suggestions:

> [I guess, these containers (<detectionElements> and <trainProtectionElements>) are meant to be implemented as children of > <ocsElements>, right?]

Yes.

- > hmm. so far, we (normally) have containers for exactly one type of
- > trackElement (e.g. <radiusChanges> with [only] <radiusChange>-elements,
- > etc.). Exception: <connections> with <switch> and <crossing>.
- > If we introduce (as proposed) a container <detectionElements> with elements
- > <detector>, <trackCircuitChange> and later others, this ("unwritten")
- > convention is broken.

I would have no problem with introducing 2 containers "detectors" and "trackCircuitBorders" instead of one container "detectionElements" resp. "tracksideMagnets" and "balises" instead of "trainProtectionElements". I think, each of these solutions would work as well as the other.

- > 3) introduce new element <detector>
- > --> maybe also later?

If nobody urgently needs it, o.k.

- > 4) discard attributes "length" and "frequency" of <trackCircuitChange>
- > --> question about 2) and 4): do we need <trackCircuitChange> _AND_
- > <trackCircuit>? Or wouldn't it suffice to have only <trackCircuit>?

If we define the borders of track circuits within the element trackCircuit, we usually have to define them twice because a track circuit border usually limits two track circuits. Another solution would be to define it once in one of the two adjecting track circuits (Which one?) and refer to it in the other track circuit. Or we define them outside the track circuit itself and have 2 references.

A border between track circuits is not always an insulated rail joint. There are also solutions like S-shaped loops or just limiting the track circuit by the length of the rail. Thus the track circuit borders will get several attributes. Thus, I prefer to define them as an extra element.

- > in the current scheme, we have the containers <trainProtectionElements>
- > AND <ballses>. Do you think balises should be reordered as a child of

> trainProtectionElements?

I intended to leave out the container "balises" and to make one container "trainProtectionElements" which contains balises and tracksideMagnets. But as mentioned above, we can also have 2 containers instead.

> *** crossings ***

I'm afraid I don't understand well the idea of 0...3 connections. 0 connections are for crossings, 1 for single crossing switches (EKW) and 2 for double crossing switches (DKW), am I right? But 3 connections? This means that a EKW has 1 connection ID (Right or wrong?), but for interlocking it needs 2 because it has 2 independent point machines with 2 independent pairs of blades.

Yours Gregor Theeg

--

Dipl.-Ing. Gregor Theeg wissenschaftlicher Mitarbeiter Professur für Verkehrssicherungstechnik der TU Dresden

Tel.: 0351 / 463 36542 Fax: 0351 / 463 36644